



Endpoint on THM EI Cloud: e.g. `iot-lab01.ei.thm.de`



## IoT Lab 2:

### Deploying Docker Container Apps on the THM EI Cloud


# Learning Objectives

- Using different cloud platform: EI IoT Cloud Platform (portainer)
- Deploy and configure container applications using a **YAML File** (Docker compose):
  - **NodeRed** with a local volume attached for persistent data + secure with password
  - **Mosquitto Broker** (no local volume is necessary)
  - **InfluxDB** with a local volume attached for persistent data
  - **Grafana** with a local volume attached for persistent data
- Use assigned **port-mapping**
- Create an easy „Sensordata“-Flow: publish local CPU load (from lab 1) via MQTT to own broker, subscribe in Node-Red in Cloud, store into database and visualize in grafana
- Subscribe to the defined topics in different ways using NodeRed, MQTT Explorer & MQTTx
- Learn how to secure your MQTT connection via TLS and how to use the secured EI MQTT Broker → used for future labs
- To deploy container there are mutiple options
  - a.) Portainer GUI (standalone or yaml file)
  - b.) Docker Command Line Interface  (*already done in Lab 1*)

# Register and login to THM EI Cloud


- Navigate to <https://cloud.ei.thm.de> \*
  - Follow **Login with OAuth**
  - Login with SSO with your THM credentials (like in Moodle, etc)
  - You should see an assigned environment, like IoT-Lab0x
- 
- \* Note: If you are not in THM network, connect via VPN client  
<https://www.thm.de/its/campusnetz/vpn.html>
- 
- Note down your **port-range** assigned to you in moodle / lecture → since you are all working on the same server, ports have to be unique per container!

your port range: \_\_\_\_\_



# Create a new stack

- **Login** to your endpoint
  - Head to “Stacks” (1) and click “Add stack” (2)
  - Choose <yourname>\_lab2\_ws20xx as the name of your stack (3)
  - Use the web editor to configure your services (4) → see next slide



The screenshot illustrates the process of creating a new stack in a Docker management interface. It is divided into two main sections: a left sidebar and a right main panel.


**Left Sidebar:** Contains a list of navigation items: Dashboard, App Templates, Stacks, Services, Containers, Images, Networks, Volumes, Configs, Secrets, and Swarm. A green arrow labeled (1) points to the **Stacks** item.

**Main Panel (Top):** Shows a header with a bell icon, a help icon, and a user profile icon. Below the header is a row of buttons: a red **Remove** button, a blue **+ Add stack** button, and a menu icon. A green arrow labeled (2) points to the **+ Add stack** button.

**Main Panel (Bottom):** Titled **Create stack**, it contains a form for creating a new stack. The **Name** field has the placeholder text "e.g. mystack". Below this is a note: "This stack will be deployed using the equivalent of the `docker stack deploy` command." Under the **Build method** section, there are four options: **Web editor** (selected with a blue checkmark), **Upload** (Upload from your computer), **Repository** (Use a git repository), and **Custom template** (Use a custom template). A green arrow labeled (3) points to the **Web editor** option. Below the build method options is a text area for the **Web editor** with the text "You can get more information about Compose file format in the [official documentation](#)." and a prompt "Define or paste the content of your docker compose file here". A green arrow labeled (4) points to this text area. At the bottom right of the text area, it says "Version: 1" and "Copy to clipboard".

# Create a new stack

- **Deploy Stack using the docker-compose web editor:**
  - Add the services Mosquitto, NodeRed, InfluxDB and Grafana
  - Change <yourname> to your name (lowercase only)
  - Change the yxxxx ports to your own ports assigned by the tutor
  - Ensure that each service has its own unique port; do not reuse ports
  - Check your configuration and deploy the stack  
don't get nervous, it takes about a minute to pull the images 😊
  - DO NOT copy from slides !!! → use the provided example
  - Attention: Indentation spaces are important



```
version: "3.8"
services:
  node-red-<yourname>:
    image: nodered/node-red:latest
    ports:
      - "yxxxx:1880"
    networks:
      - <yourname>_net
    volumes:
      - <yourname>_nodered_vol:/data

  mosquitto-<yourname>:
    image: eclipse-mosquitto:1.6.13
    ports:
      - "yxxxx:1883"
    networks:
      - <yourname>_net

  influxdb-<yourname>:
    image: influxdb:latest
    ports:
      - "yxxxx:8086"
    networks:
      - <yourname>_net
    volumes:
      - <yourname>_influx_vol:/var/lib/influxdb2:rw

  grafana-<yourname>:
    image: grafana/grafana:latest
    ports:
      - "yxxxx:3000"
    networks:
      - <yourname>_net
    volumes:
      - <yourname>_grafana_vol:/var/lib/grafana:rw

volumes:
  <yourname>_nodered_vol:
  <yourname>_influx_vol:
  <yourname>_grafana_vol:

networks:
  <yourname>_net:
```

# YAML File (some theory)

- **YAML** stands for “**YAML Ain’t Markup Language**” — it’s a simple, human-friendly format used to describe data. Think of it like a “recipe” that tells a system what to do.
- In the context of **Docker** or **Kubernetes**, YAML files are used to define:
  - Which containers to run
  - What settings they should have
  - How they should connect to each other (networking)
  - How many copies (scaling)
  - And more...
- **What happens behind the scenes?**
  - Once you write and run the YAML file:
  - Containers are **automatically deployed**
  - Docker (or Kubernetes) **manages** the services
  - **Scaling, networking, restart policies** — all are automated
- **So what do we need to define?**
- Just **what we want**, like:
  - The container image (e.g., nginx, node, mysql), Port mapping (e.g., 8080:80), Environment variables(opt), volumes, etc.

- This example tells Docker:
  - Run **nginx** web server (well-known port **80**)
  - Make it accessible from **port 8080** on our computer

```
version: "3.9"
services:
  web:
    image: nginx
    ports:
      - "8080:80"
```

# YAML File Format



## First level

Web editor

You can get more information about Compose file format in the [official documentation](#).

Remember **first level keywords**

```
1 version: "3.7"
2
3 services:
4
5
6
7
8
9 networks:
10
11 volumes:
12
13 configs:
14
15 secrets:
16
17
```


# YAML File Format

How to write a YAML file:

- No Spaces
- No Upper Case Letters
- Use either Tab key or 2 spaces

Tab key or 2  
spaces

1st level  
2nd level  
3rd level



```
1 versions: "3.8"
2
3 services:
4   nodered:
5     image: nodered/node-red:latest
6     ports:
7       "6008:1880"
8   database:
9     image: bitnami/mongodb:latest
10
11
12 networks:
```



# Access your applications

- Note down your IPs / Ports to access your applications:

- Node-Red

Public IP: \_\_\_\_\_ Public Port: \_\_\_\_\_  
Private IP: \_\_\_\_\_ Private Port: \_\_\_\_\_

- Mosquitto

Public IP: \_\_\_\_\_ Public Port: \_\_\_\_\_  
Private IP: \_\_\_\_\_ Private Port: \_\_\_\_\_


- InfluxDB

Public IP: \_\_\_\_\_ Public Port: \_\_\_\_\_  
Private IP: \_\_\_\_\_ Private Port: \_\_\_\_\_

- Grafana

Public IP: \_\_\_\_\_ Public Port: \_\_\_\_\_  
Private IP: \_\_\_\_\_ Private Port: \_\_\_\_\_

Endpoint on THM EI Cloud: e.g. `iot-lab01.ei.thm.de`




# Configure Node Red & MQTT


- Open **NodeRed** on your local computer (from lab 1)
  - Publish the CPU Data to either your broker (a) or EI Broker (b)  
(a) use your own broker via

Public IP: \_\_\_\_\_ Public Port: \_\_\_\_\_  
Private IP: \_\_\_\_\_ Private Port: \_\_\_\_\_

(b) Use EI Broker: **mqtt.ei.thm.de:1993** user/pw: **iotlab/iotlab** Topic format: **THM/IoTLab/yourname**




- Open **NodeRed** deployed on cloud (this lab)
  - subscribe to your published data and show values in debug



```
9.8.2022, 14:51:58 node: debug 1
THM/IoTLab/Weber/CPU : msg : Object
▼ object
  topic: "THM/IoTLab/Weber/CPU"
  payload: 0.5833333333333334
  qos: 2
  retain: false
  _msgid: "0555fba9bacdf2ef"
```

# Configure InfluxDB


- **Open InfluxDB**
  - Walk through the Get Started guide and setup initial user
    - Choose a username and password and **note it down**
    - Choose the Organization Name: THM
    - Name your data bucket: lab02



The screenshot shows the 'Setup Initial User' interface of InfluxDB. At the top, it says 'Setup Initial User' and 'You will be able to create additional Users, Buckets and Organizations later'. Below this, there are four input fields: 'Username', 'Password', 'Confirm Password', and 'Initial Organization Name'. The 'Initial Organization Name' field has a help icon and a tooltip that says 'An organization is a workspace for a group of users.' Below these, there is another input field for 'Initial Bucket Name' with a help icon and a tooltip that says 'A bucket is where your time series data is stored with a retention policy.'



# Configure InfluxDB

- **Save your InfluxDB API key (use e.g. editor)**
  - Make a note of the API key, as we'll be using it later.
  - → COPY TO CLIPBOARD not always working, so copy manually !!



# Configure InfluxDB

- **Configure InfluxDB**
  - Click “Load your data” on the Getting Started Page
  - In the “Data” menu, head to Buckets and change the retention policy in “settings” if needed



# Configure InfluxDB in NodeRed

## ■ Add InfluxDB Server to Node Red (cloud)

- Go back to your Node Red Service and add an influxdb out node
  - needs to be installed → manage palette
- Configure a new InfluxDB Server and select version 2
- Enter your URL (**http:// + IP/FQDN cloud endpoint or local Container IP or service name + port** of InfluxDB) and the copied admin token
- Add the configuration
- Edit the influxdb out node and enter your organization, bucket, measurement
  - Organization: THM
  - Bucket: lab02
  - Measurement: CPU\_PC



Node 'influxdb out' bearbeiten > Neuen Konfigurations-Node 'influxdb' hinzufügen

Abbrechen Hinzufügen

**Eigenschaften**


Name InfluxDB

Version 2.0

URL **http://(Your PC IP / local Container IP / servicename):port**

Token

☒ Verify server certificate



Node 'influxdb out' bearbeiten

Löschen Abbrechen Fertig

**Eigenschaften**

Name mymeasurement

Server [v2.0] InfluxDB

Organization THM

Bucket lab02


Measurement CPU\_PC

Time Precision Milliseconds (ms)

# Configure InfluxDB

## ■ View your measurements



- On your InfluxDB Web-UI go to the Explore menu
- You can now select your bucket and view your measurements and click submit



# Configure Grafana

- **Open the Grafana Web Interface**

- Login with the default user/password combination (admin/admin)
- Choose a new password and **note it down**
- On the Grafana Homepage click the “Add your first data source” Panel
- Add InfluxDB as a source







# Configure Grafana

## ■ Add InfluxDB to Grafana

- Change the Query Language to **Flux**
- Enter the URL and Port of your InfluxDB
- Disable Basic Auth
- Enter your **Organization**, **Token** and **Default Bucket** under "InfluxDB Details"
- Click save and test → should be green and successful




The screenshot shows the 'InfluxDB Details' configuration panel. It contains several input fields: 'Organization' with the value 'THM', 'Token' with the value 'configured', and 'Default Bucket' with the value 'lab02'. There is a 'Reset' button next to the Token field. Below these are 'Min time interval' set to '10s' and 'Max series' set to '1000'. Each of these last two fields has an information icon (i) to its left.



The screenshot shows two configuration panels. The top panel is 'HTTP' and contains 'URL' (with a placeholder 'Your IP and port'), 'Allowed cookies' (with a 'New tag (enter key to add)' field and an 'Add' button), and 'Timeout' (with a placeholder 'Timeout in seconds'). The bottom panel is 'Auth' and contains 'Basic auth' (with a toggle switch and a 'With Credentials' label) and 'TLS Client Auth' (with a toggle switch and a 'With CA Cert' label).

# Configure Grafana


- **Create a dashboard and display measurements**
  - Click on the “Create your first dashboard” panel at the Homepage of Grafana
  - Add visualization and select your influxdb as data source



# Configure Grafana

- **Go back to your InfluxDB Explorer**


- Choose your bucket and a measurement you want to visualize (value)
- Click on the script editor button
- Copy the query text for Grafana



```
1 from(bucket: "IOT2025")
2   |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
3   |> filter(fn: (r) => r["_measurement"] == "Weber_Office")
4   |> filter(fn: (r) => r["_field"] == "Temp")
5   |> aggregateWindow(every: v.windowPeriod, fn: last, createEmpty: false)
6   |> yield(name: "last")
```

# Configure Grafana



- Insert the copied Query text in your Grafana raw query editor



```
1 from(bucket: "IOT2025")
2 |> range(start: v.timeRangeStart, stop: v.timeRangeStop)
3 |> filter(fn: (r) => r["_measurement"] == "Weber_Office")
4 |> filter(fn: (r) => r["_field"] == "Temp")
5 |> aggregateWindow(every: v.windowPeriod, fn: last, createEmpty: false)
6 |> yield(name: "last")
```

# Configure Grafana

- Now your turn:
  - Give a title, description and the correct unit
    - Fine tune your graph if you want to
    - Click apply if you are done and **save your dashboard**  
It will not be saved automatically!



The image shows the "Panel options" sidebar in Grafana. It includes a search bar, tabs for "All" and "Overrides", and several expandable sections: "Panel options" (Title: "Temperature", Description: empty text area, Transparent background: toggle), "Panel links", "Repeat options", "Tooltip" (Tooltip mode: "Single", "All", "Hidden"), "Legend" (Legend mode: "List", "Table", "Hidden", Legend placement: "Bottom", "Right", Legend values: "Choose" dropdown), and "Graph styles" (Style: "Lines", "Bars", "Points").

# Experiment with MQTT Clients

- MQTT Explorer
- Open MQTT Explorer (already installed in Lab)
  - Add a new connection Server: either your own broker or EI broker
  - Subscribe to your topic and show your data

+

Connections

Mosquitto in EI Cloud

mqtt://iot-seminar.ei.thm.de:50004/

test.mosquitto.org

mqtt://test.mosquitto.org:1883/

MQTT Connection

mqtt://iot-seminar.ei.thm.de:50004/

Name

Mosquitto in EI Cloud

Validate certificate

☒

Encryption (tls)

☐

Protocol


mqtt://

Host

iot-seminar.ei.thm.de


Port

50004



# Experiment with MQTT Clients

- **MQTTx**
- **Open MQTTx (now we use TLS on EI Broker)**
  - Add a new connection Server: either your own broker or EI broker
  - Subscribe to your topic and show your data



The image shows the MQTTx configuration interface. It includes fields for Name, Host, Port, Client ID, Username, Password, SSL/TLS toggle, SSL Secure toggle, ALPN, and Certificate selection.

\* Name: EI\_Broker (student)

\* Host: mqtt://

\* Port: 9993

Client ID: mqttx\_b3846970

Username: iotlab


Password: .....

SSL/TLS: ☒

SSL Secure: ☒ ⓘ

ALPN:

Certificate: ☒ CA signed server certificate ☐ CA or Self signed certificates



# Add Authentication to NodeRed

## ■ Option 1: Modify setting.js file to define username&password

- Go to your NodeRed volume and download setting.js, go to // securing node red section in this file
- Uncomment this string including the users key value which has one item defined as a JSON Object
  - JSON Objects defines: Username, password and permissions
  - We can generate the hash of the password via a hashfunction:  
`password: require('bcryptjs').hashSync("cloud2021")`  
Library bccrpyt includes the hashSync function which returns the hash value of the password
  - Rename old setting.js to setting.js.backup and upload modified file including the password
  - Go to your stack, choose NodeRed and update it => NodeRed will be restartet and reads the settings.js file
  - Login with your username and password
  - **Don't forget to logout in NodeRed on the upper right corner!**



```
// Securing Node-RED
// -----
adminAuth: {
  type: "credentials",
  users: [{
    username: "admin",
    password: require('bcryptjs').hashSync("cloud2021"),
    permissions: "*"
  }]
},
```

## ■ Not used now: Option 2: Using an environment Variables to define username & pw

- Environment variables exist at the runtime of the container
- Modify your deployment stack file (YAML) and define username and password
- Update your settings.js file to read the new environment variable:
  - Go to your nodered volume
  - Download settings.js file
  - Rename the original setting.js file into setting.js.backup
  - Modify it according to the slide on the next page & upload it again
  - Restart the NodeRed app and login with the username and password to node red
  - Modify the password in the deployment file and test if it works!

```
version: "3.8"

services:
  nodered1:
    image: nodered/node-red:latest
    ports:
      - "50002:1000"
    environment:
      - NODERED_MY_PASSWORD=cloud2021
      - NODERED_MY_USERNAME=me
    networks:
      network2:
    volumes:
      - nodered1-v:/data
```





# Modifying the file settings.js on volume

//All the way on the to in settings.js enter the following function:

```
my_function = ()=> {
```

```
    username = process.env.NODERED_MY_USERNAME
```

```
    password = process.env.NODERED_MY_PASSWORD
```

```
    return {
```

```
        username,
```

```
        password
```

```
    }
```

```
}
```

```
// Securing Node-RED
```

```
// -----
```

```
// To password protect the Node-RED editor and admin API, the following
```

```
// property can be used. See http://nodered.org/docs/security.html for details.
```

```
adminAuth: {
```

```
    type: "credentials",
```

```
    users: [{
```


```
        username: my_function()['username'],
```

```
        password: require('bcryptjs').hashSync(my_function()['password']),
```

```
        permissions: "*"
```

```
    ]
```




```
},
```



# Lab Summary

## El IoT Cloud platform, Docker compose, secure IoT services and MQTTs

In this lab, you learned to:

- **Deploy IoT Applications in the Cloud** 
  - Use Portainer GUI and Docker Compose YAML for container deployment
  - Manage Node-RED, Mosquitto, InfluxDB, and Grafana with volume and port configuration + securing NodeRed with username and password
- **Build and Visualize IoT Data Flows** 
  - Publish system metrics via MQTT
  - Subscribe in Node-RED (cloud)
  - Store in InfluxDB
  - Visualize using Grafana dashboards
- **Work Securely with MQTT** 
  - Subscribe using multiple clients (Node-RED, MQTT Explorer, MQTTx)
  - Secure connections with TLS
  - Use the **EI MQTT Broker** with certificates

 You now understand

- multi-container deployment
- cloud workflows
- **MQTT and service security**
- → all essential for scalable IoT solutions.

# Lab 2 Review & Reflection

- What is the purpose of Docker Compose?
- Which services did you deploy using a YAML file?
- Why is port mapping necessary in container-based applications?
- How do you persist data for containers like Node-RED, InfluxDB, and Grafana?
- What is the purpose of an MQTT Broker? Which are the well-known ports?

# Lab 2 Review & Reflection

- What is TLS and why is it important for MQTT communication?
- Which elements are used to secure connection to the used MQTT Broker?
- Create a topology for this lab (template is provided)